

Accessories for insert modules

Available rear panels "R 1 - R 3 / R 5"

- when viewed from the rear, the male and female connector cut-outs are located on the right hand side

1 = no. for order example; 2 = dimensioned drawing; 3 = fitting to connectors

1	2	3
R 1		
R 2	11,9	DIN 41612 DIN 41617
R 3	15,7	DIN 41612
R 5	7,6	suitable for all connectors complying to DIN 41612 and for insert modules L, W